



Spikes-Spider is the convenient alternative to snow chains and studded tires. It's designed to be installed anytime, anywhere, by anyone in just 30 seconds.

These text instructions are the script for the video demonstration available at Spikes-SpiderUSA.com.

INSTALLING SPIKES-SPIDER COMPACT

You can adjust the size of your Compact by inserting the traction arm into the back of the disc and rotating to align the letter specified in the included tire chart.

To install, first remove the decorative hub cover. Then spread the bottom two traction arms to place one in front of the tire and one behind. Push the traction element around the tire. In some instances, you may need to use your knees for extra support. Lastly, insert the locking ring and turn until the red security grip snaps into place.

To remove, pull the red security grip and turn until it releases from the hub plate.

Then pull the traction element off the tire.

Repeat this on the other side, and then move the vehicle to free the bottom two traction arms.

Remember to reattach your decorative hub cover.